

HWP-Pro

Touch protection
Protection of hot-wire probe tips
Two designs to fit the different probe types
Easy application

Description

The touch protection safely protects the hotwire probe tip when the probe is not in operation. The device is made of PA plastic. To put on the protection, the probe is inserted into the slot and pulled back into the protective cover. Finally, the probe is secured with the built-in twist lock.

The protection is available in two designs. For probes of the type HWP10/90 and HWP10/45 the narrow version HWP-ProS is necessary. All other probes require the larger version HWP-ProM.

Order Options

| HWP-ProS | for HWP10/90 and HWP10/45 |
|----------|---------------------------|
| HWP-ProM | all HWP10/xx |

Handling (Exemplary for ProM)

1) Hot-wire probe and touch protection



3) Pull back and fixate the probe with thumb



2) Insert and position the probe



4) Secure with twist lock

